



## Removing and replacing head seal



1. Lever out shower screen by working around head with a small screw driver.



2. Screen will gradually work out of it's fitting.



3. Rubber head seal and screen will eventually detach from the group head. Be careful as they will be hot!



4. Discard worn or broken seal. Clean the shower screen so it is clear of all coffee residue, or replace if necessary. Also scrub underside of group head to remove any build up.



5. Put new seal and screen together, beveled edge of seal faces up. Press into place gently with a screwdriver. Make sure it is snug and level. Check to ensure there are no bulges.



6. To ensure correct placement, remove the basket from the handle and lock into place, as if making coffee. Twist firmly to right as far as it will go.